

# Work Area Outlets


## Wire Junction Box



- Allows additional extensions to be added to an existing telephone system
- Terminals are a combination screw and insulation displacement so that terminations can be made with or without stripping wires
- Includes mounting screws

Part Number	Part Description	Std. Pkg. Qty.	Std. Ctn. Qty.
AT742A	E/W 4 Cond., 6 Pos. 1 Ft Modular Cord Ivory	1	100
AT742B	Not Equipped with modular cord	1	100


## Surface Jack



- Modular jack mounted into an ivory cover and a 42A4 or 42A6 connecting block as appropriate
- Includes mounting screws
- UL and CSA Listed

Part Number	Part Description	Std. Pkg. Qty.	Std. Ctn. Qty.
AT214B4	4 Cond., 6 Pos. Surface Jack Ivory	25	200
AT214B6	6 Cond., 6 Pos. Surface Jack Ivory	25	200

## Surface Jack Cover



- Ivory cover has integral jack with spade-tipped leads
- Converts existing 42A connecting blocks to modular
- UL Listed and CSA Listed

Part Number	Part Description	Std. Pkg. Qty.	Std. Ctn. Qty.
AT214C4	4 Cond., 6 Pos. Surface Jack Cover	25	200
AT214C6	6 Cond., 6 Pos. Surface Jack Cover	25	200

## Connecting Block



- 4 or 6 terminal connecting block
- Includes cover, terminal screws and washers
- Used primarily to terminate inside wiring telephone cable
- Includes mounting screws
- UL Listed and CSA Listed

Part Number	Part Description	Std. Pkg. Qty.	Std. Ctn. Qty.
AT42A4	4-Terminal Connecting Block Ivory	50	400
AT42A6	6-Terminal Connecting Block Ivory	50	400

## Voice Connecting Block



- For connecting registered voice equipment to the switched network
- Typical use of these blocks is the connection of alarm and automatic dialers, recording equipment, answering machines and facsimile devices
- Includes mounting screws
- UL Listed and CSA Listed

Part Number	Part Description	Std. Pkg. Qty.	Std. Ctn. Qty.
AT635B (RJ31X-RJ38X)	1-6 Cond., 6 Pos., 1-8 Cond., 8 Pos. with Shorting Bars on Pins 1-4 and 5-8	1	100